

## Bottle Filler Solutions Hydration and Wellbeing®




















Student hydration and wellbeing is a top priority

Students need to be able to access water to refill their water bottles

Enware bottle fillers are a great alternative to bubblers

**“Swap and Go”**  
Simply remove existing bubbler and replace with an Enware Bottle Filler



PART NUMBER	TROUGH/MOUNTING TYPE	ACTIVATION	INLET SIZE	FLOW RATE	PART NUMBER	TROUGH/MOUNTING TYPE	ACTIVATION	INLET SIZE	FLOW RATE
 <b>BUBBFRWE-R</b> Activation Right Side	Wallsend	Push Button (Right Hand Side) Suitable for mounting on left end of trough	1/2" BSP (15mm)	5 L/min	 <b>BUBBFRWEL-PBR</b> Activation Right Side Filler at Left	Wallsend with Lid	Push Button (Right Hand Side)	1/2" BSP (15mm)	5 L/min
 <b>BUBBFRWE-L</b> Activation Left Side	Wallsend	Push Button (Left Hand Side) Suitable for mounting on right end of trough	1/2" BSP (15mm)	5 L/min	 <b>BUBBFRW-PB</b> Activation at Front	Wall Mount	Push Button	1/2" BSP (15mm)	5 L/min
 <b>BUBBF224-WE-C</b> Type 63 Activation Right Side Filler at Front	Wallsend	Cam Action	1/2" BSP (15mm)	5 L/min (Adjustable 2-7 L/min)	 <b>BUBBF219-C</b> Type 100 Activation at Front Filler at Left or Right	Wall Mount	Cam Action	1/2" BSP (15mm)	5 L/min (Adjustable 2-7 L/min)
 <b>BUBBF224-WE-LVR</b> Type 63 Activation Right Side Filler at Front	Wallsend	Lever Action	1/2" BSP (15mm)	5 L/min (Adjustable 2-7 L/min)	 <b>BUBBF219-LVR</b> Type 100 Activation at Front Filler at Left or Right	Wall Mount	Lever	1/2" BSP (15mm)	5 L/min (Adjustable 2-7 L/min)
 <b>BUBBFRWEL-CR</b> Activation Right Side Filler at Left	Wallsend with Lid	Cam Action (Right Hand Side)	1/2" BSP (15mm)	5 L/min	 <b>BUBBFW-PB95</b> Activation at Front Filler Underneath	Wall Mount	Push Button	1/2" BSP (15mm)	5 L/min
 <b>BUBBFRWEL-CL</b> Activation Left Side Filler at Right	Wallsend with Lid	Cam Action (Left Hand Side)	1/2" BSP (15mm)	5 L/min	 <b>BUBBFRH-PB</b> Activation at Front	Hob Mount Replacement for Enware DFSA120 and DFSA121 Chillers	Push Button	1/2" BSP (15mm)	5 L/min
 <b>BUBBFRWEL-LL</b> Activation Left Side Filler at Right	Wallsend with Lid	Lever (Left Hand Side)	1/2" BSP (15mm)	5 L/min	 <b>BUB302B</b> Activation at Top Filler at Front	Hob Mount	Push Button	1/2" BSP (15mm)	5 L/min
 <b>BUBBFRWEL-LR</b> Activation Right Side Filler at Left	Wallsend with Lid	Lever (Right Hand Side)	1/2" BSP (15mm)	5 L/min	 <b>BUBBFGFH-C150</b> 312mm Tall Gooseneck Spout Fixed Activation right side, filler at front	Hob Mount	Cam Action	1/2" BSP (15mm)	8 L/min
 <b>BUBBFRWEL-PBL</b> Activation Left Side Filler at Right	Wallsend with Lid	Push Button (Left Hand Side)	1/2" BSP (15mm)	5 L/min	 <b>BUBBFGSH-C150</b> 350mm Tall Gooseneck Spout Fixed Activation right side, filler at front	Hob Mount	Cam Action	1/2" BSP (15mm)	8 L/min
					 <b>BUB268B</b> Activation at Front Filler Underneath	Wall Mount	Push Button	1/2" BSP (15mm)	5 L/min